

I'm not a robot



The dimensions of Over-the-Range Microwaves have remained consistent over the years. New models are designed to fit into the same overhead cabinet opening width of 30 inches and cabinet depth of 12 inches minimum to 13 inches maximum as previous models. All 30" Over-the-Range Microwaves are approximately the same width and are designed to fit into a 30" wide cabinet opening. Therefore, any of our current 30" Over-the-Range Microwave models will work as a replacement for an existing 30" Over-the-Range Microwave model (see below for information on replacing a 36" Over-the-Range Microwave model). Each Microwave comes with the mounting hardware (mounting bracket, screws, exhaust adapter), top and rear templates, and installation instructions needed to complete the installation process. This makes choosing a replacement Microwave very easy. NOTE: When replacing an Over-the-Range Microwave, the mounting bracket included with the new Microwave should be used since the mounting bracket is specific to each model. The new screws, bolts and exhaust adapter should also be used. You can view our current Over-the-Range Microwave models on the GE Appliances website and narrow the choices by color, features and more. If you are replacing a 36" Over-the-Range Microwave, many current 30" Over-the-Range Microwaves offer an optional 36" filler kit to allow it to be installed in a 36" wide cabinet opening. If available for a specific model, the filler kit will be listed in the product Specs & Details tab on our website. View all 36" filler kits. Filler kits can be ordered through our GE Appliances Parts & Accessories website, if needed. Whether a repair or a replacement, we are available to provide expert guidance with each decision. Please reach out to us for help with every appliance need! Hello. You have to determine which part failed. Take the bottom cover off, disconnect the plug from the turn table motor and using the multimeter check voltage stated on the name tag of the motor. If there is no voltage - bad control board. If you are reading voltage, check the motor for continuity. No continuity - replace the motor. Continuity present - take two screws out, drop the motor down and remove the coupler out (from inside the cavity). If its bad - replace it. The turn table motor AP2024962 The coupler AP2016754 Her are the breakdown diagrams and Microwave replacement parts for General Electric JVM1870BF02 Counter top microwave | AppliancePartsPros.com Thank you. Post the results. Simon.

Ge spacemaker xl1800 replacement. Ge spacemaker xl1800 replacement parts. Ge profile spacemaker xl1800 replacement parts. Ge spacemaker xl1800 replacement model troubleshooting. Ge profile spacemaker xl1800 replacement model.